

## CB Antenna Mount JK

Contents: (1) CB Antenna Mount  
(2) 8 x 40mm Hex Bolts  
(2) 8mm Lock Washers  
(2) 8mm Flat Washers



PLEASE REVIEW ALL INSTRUCTIONS BEFORE YOU BEGIN.

Note: CB Antenna mount has (2) mounting holes. Either hole may be used .

Step 1. Remove the spare tire from your factory mount.



Step 2. Remove the (2) top right hand 13mm hex bolts from the spare tire mount.



Step 3. Install the CB Antenna Mount using the supplied hex bolts, lock washers, flat washers. Torque bolts to 10 ft-lbs. Remount the spare tire after CB Antenna installation is complete.



For Technical Assistance Contact:  
OMIX-ADA Tech Support  
Phone: 1-800-449-6649  
Email: [techsupport@omix-ada.com](mailto:techsupport@omix-ada.com)  
Web: [www.Omix-Ada.com](http://www.Omix-Ada.com)